



Contents

Device	Part number	Quantity	Calibration Option ^a
Open circuit plug	64S12L-000S3	1	FC
Open circuit jack	64K12L-000S3	1	FC
Short circuit plug	64S12S-000S3	1	FC
Short circuit jack	64K12S-000S3	1	FC
Calibration load plug	64S150-C10S3	1	FC
Calibration load jack	64K150-C10S3	1	FC
Calibration adaptor plug/plug	64S121-S20S3	1	FC
Calibration adaptor jack/jack	64K121-K20S3	1	FC
Calibration adaptor plug/jack	64S121-K20S3	1	FC
Calibration adaptor RPC-N plug / 4.3-10 plug	05S164-S20S3	1	FC
Calibration adaptor RPC-N jack / 4.3-10 jack	05K164-K20S3	1	FC
Combi wrench	64W002-000	1	-
Torque wrench 2.0 Nm	64W021-000	1	FC

a. See "Declaration of calibration options" for explanation.

Dieses Dokument ist urheberrechtlich geschützt • This document is protected by copyright • Rosenberger Hochfrequenztechnik GmbH & Co. KG

RF_35/05.10/6.1

Documentation

This kit is delivered with

- **USB-Stick**
Standard Definitions as data files for Vector Network Analyzer Families PNA (Keysight/Agilent) and ZVA (Rohde&Schwarz). Calibration Certificate as PDF-file.
- **Standard Definitions Cards**
Printed Standard Definitions that can be used on nearly all Vector Network Analyzers.
- **Kit Info Card**
Handling precautions and information for installing Standard Definitions on a Vector Network Analyzer.
- **Calibration Certificate**
Details see "Declaration of calibration options"
- **Operating Manual**

Electrical specifications

This specification covers electrical key values for the main calibration standards of the calibration kit. Specific datasheets are available for each component among the part number.

Calibration standard	Frequency	Parameter	Specification
Opens^b (plug and jack)	DC to ≤ 4 GHz > 4 GHz to ≤ 6 GHz > 6 GHz to ≤ 12 GHz	Error from Nominal Phase	≤ 2.0° ≤ 2.5° ≤ 3.0°
Shorts^b (plug and jack)	DC to ≤ 4 GHz > 4 GHz to ≤ 6 GHz > 6 GHz to ≤ 12 GHz	Error from Nominal Phase	≤ 2.0° ≤ 2.5° ≤ 3.0°
Calibration loads (plug and jack)	DC to ≤ 4 GHz > 4 GHz to ≤ 6 GHz > 6 GHz to ≤ 12 GHz	Return Loss	≥ 40 dB ≥ 35 dB ≥ 25 dB
Calibration adaptors In-series (plug/plug and plug/jack)	DC to ≤ 4 GHz > 4 GHz to ≤ 6 GHz > 6 GHz to ≤ 12 GHz	Return Loss	≥ 35 dB ≥ 32 dB ≥ 25 dB
Calibration adaptors In-series (jack/jack)	DC to ≤ 4 GHz > 4 GHz to ≤ 6 GHz > 6 GHz to ≤ 9 GHz > 9 GHz to ≤ 12 GHz	Return Loss	≥ 35 dB ≥ 32 dB ≥ 25 dB ≥ 18 dB
Calibration adaptors Inter-series (plug/plug and jack/jack)	DC to ≤ 4 GHz > 4 GHz to ≤ 6 GHz > 6 GHz to ≤ 12 GHz	Return Loss	≥ 34 dB ≥ 30 dB ≥ 25 dB

b. The specifications for opens and shorts are given as allowed deviation from nominal model as defined in calibration certificate included with your kit.

Declaration of calibration options

Factory Calibration

Standard delivery for this kit includes a Factory Calibration. The Calibration Certificate issued reports individual calibration results, **traceable to Rosenberger standards**, national / international standards are not available. Model based standard definitions of the calibration standards are reported in Agilent/Keysight, Rohde & Schwarz and Anritsu compatible VNA format.

Accredited Calibration

Not available.

For further, more detailed information see application note AN001 on the Rosenberger homepage.

Calibration interval

Recommendation 12 months

While the information has been carefully compiled to the best of our knowledge, nothing is intended as representation or warranty on our part and no statement herein shall be construed as recommendation to infringe existing patents. In the effort to improve our products, we reserve the right to make changes judged to be necessary.

Draft	Date	Approved	Date	Rev.	Engineering change number	Name	Date
F. Reiner	31.08.16	M. Moder	02.03.2018	a01	18-0008	M. Knoll	02.03.2018
Rosenberger Hochfrequenztechnik GmbH & Co. KG P.O.Box 1260 D-84526 Tittmoning Germany www.rosenberger.de					Tel. : +49 8684 18-0 Fax : +49 8684 18-499 Email : info@rosenberger.de		Page 3 / 3