
Technical Data Sheet

Rosenberger

Cable assembly RPC-1.35 Jack – UT-047-LL – RPC-1.35 Jack

L70-420-XXX



All dimensions are in mm; tolerances: \pm 3mm for A \leq 300 mm; \pm 1% for A > 300 mm *) If length "A" \leq 90 mm marking is mount centric \pm 5mm

Avai	lable	variants

Type	max. Insertion loss	Marking	Weight (g) / pce		
L70-420-XXX	$\leq 0.0017 * \sqrt{f[GHz]} \frac{dB}{mm}$	ROSENBERGER YYYY-WW L70-420-XXX sssss	$0.0059 \frac{g}{mm} * A[mm] + 2.60g$		

XXX – length in mm = A Maximum possible length = 6000mm WW – week YYYY – year sssss – serial no.

Note: Weight:

First constant = Cable weight per mm; Second Constant = Connector left and Connector right weight per pce

Assembly parts

Connector left RPC-1.35 Jack
Connector right RPC-1.35 Jack
Cable UT-047-LL
Armour none

Electrical data

Impedance 50 Ω

Frequency DC to 90 GHz

Return loss¹ \geq 17 dB, DC to 50 GHz \geq 14 dB, 50 to 90 GHz Insertion loss¹ see table available variants

Individual testing and documentation:

Measurement plot with all 4 S – Parameters (S11; S22; S21; S12) is included with the cable assembly and on the backside the care and handling instruction is printed.

Mechanical data

Minimum bend radius:

Single 20.0 mm

Environmental data

Temperature range - 40 °C to +125 °C

RoHS compliant

While the information has been carefully compiled to the best of our knowledge, nothing is intended as representation or warranty on our part and no statement herein shall be construed as recommendation to infringe existing patents. In the effort to improve our products, we reserve the right to make changes judged to be necessary.

Draft	Date	Approved	Date		Rev.	Engineering change number	Name		Date
Marcel Panicke	08.11.19	Markus Müller	05.12.19		a00	19-s271	Marcel Panicke	Э	05.12.19
Rosenberger Hochfrequenztechnik GmbH & Co. KG					Tol	40 0604 10 0			Page

Rosenberger Hochfrequenztechnik GmbH & Co. KG P.O.Box 1260 D-84526 Tittmoning Germany www.rosenberger.de

Tel. : +49 8684 18-0 Email : info@rosenberger.de

1/1

¹ Return Loss and Insertion Loss includes the measurement adaptor